


Quick Start Guide - Function Generator Amplifier



Step 1-A: Plug in the AC power cord (not shown)


Step 1-B: Turn on the TS250 by press the LINE switch

Step 1-C: Adjust the OFFSET knob to set the voltage to 0V or release the ON/OFF button to disable offset

Step 1-D: Enable the OUTPUT by press the ON/OFF button

Step 1-E: Typical input setting: DC, 50Ω, 0dB

Current or Voltage Amplifier Connection Diagram



Visit our website to download additional documents such as datasheet and Application Notes.

<http://www.accelinstruments.com/Download/Download.html>